AP22 Analog Display

Suitable for:

- Displaying position and velocity
- Limit switches with hysteresis



For sensors with analog interface

- Programmable voltage input -10..+10 V or
- Programmable current input -20..+20 mA

General

The AP22 is designed to display position and velocity, to be used as an electronic camshaft and has the abilities to solve complex and unusual applications.


For this, the AP22 uses a 16 bit analog sensor input. The input is able to handle all signals within the range of -10..+10V or -20mA..+20mA. The position and velocity values can be adjusted through a set of parameters.

Main features:

- 8 digit display, digit height 10mm
- RS232 communication
- Programmable analog input
- 12 limit switches, 4 optional digital outputs

Programming

The AP22 can be programmed by using the front keys. Another possibility is to use the PC-program DST2. This software allows easy access to and overview of all parameters. The settings of the display controller can be stored on your harddrive. The communications with the AP22 are ASCII based RS232; it is possible to connect the AP22 to other PC-software.



Display for position and velocity

The sensor value is adjusted by the programmable parameters. The value can be converted to any desired unit, e.g. mm, meters or mm/sec. This value can be displayed on the 8 digit display of the AP22. Based on the actual display value limit switches or cams can be programmed.

Cam controller

It is possible to freely program a total of 12 cams. These cams can be assigned to 4 different outputs. It is also possible to program the cams with a hysteresis.

The response time for the AP22 is no more than 250 microseconds (1 cycletime).

Applications

Many applications can be solved by using the display controller AP22. A few possibilities:

- Speed measurement
- · Cam generator
- Over-/underspeed monitoring

Overview connections

Sensor:

Analog

The 16 bit analog input is freely programmable within the range of -20..+20mA or -10..+10V. This freedom offers the possibility to connect all regularly used signals: 0..±20mA, 4..20mA, 0..10V, 0.. ±10V and so on.

RS232 communication

The ASCII-protocol is used to communicate with the AP22. The PC-software DST2 uses this protocol to enable easy programming with the PC.

Logical inputs and outputs

The AP22 has 4 digital inputs and 4 digital outputs.

For example the following functions can be assigned to the *inputs*:

- Store
- Keylock
- Start / stop cams
- Etc


For example the following functions can be assigned to the *outputs*:

- Cams
- Error
- Cams active
- Etc.

Technical Data

Supply voltage	1035 V DC
consumption	< 150 mA (without sensor-consumption)
Output voltage	For external sensor
+ Ud	max 400 mA depending on supply voltage
+5V	max 400 mA
Max. counting range	-9999999+99999999
Cycle time	250 μs (fixed)
Analoge input	Galvanically isolated
Voltage input	max10 V +10 V; 16 bit
Current input	max20 mA +20 mA; 16 bit
Digital inputs 12	Optically isolated; low: 0+5 V; high: +10 V+35 V
Input resistance	Appr. 1.8 kΩ at 24 V
Digital outputs 14	Optically isolated, N FET, short-citcuit proof; Imax 500 mA
Supply voltage	35 V max.
Serial port	Ser-1 RS232 C
Display	8 digit 7-segment LED; digit-height 10 mm
Temperature range	050℃
ЕМС	According to EMC directive 2004/108/EC
	emission NEN-EN-IEC61000-6-3:2007
	immunity NEN-EN-IEC61000-6-3:2005
Weight	< 0.25 kg
Sealing	front: IP50; rear: IP20

Typekey





Accessories

CDS-B02 transparant protective DIN-hood with lock - IP54

CDS-B22 transparant cover made from soft plastic - IP65 (keys accessible)

EMC-B02 EMC-bracket to connect cables and shielding

Scope of delivery

Connectors, 2 fixings and EMC-bracket are within the scope of delivery. A CD with manuals and software is included.